


Operating your G646 Chair


• Seat Height:

Lift up left-hand handle. Press down on or remove weight from seat. Seat is locked at the height at which handle is released.




• Backrest Height Adjustment:

Press the button at the bottom of the backrest and raise or lower to the required position. Release the button to lock.




• Seat Depth:

Press the button under the seat upwards, slide with the seat into the desired position. Release the button to lock in position.




• Back Lock

Push down the right-hand handle and lean against the backrest to recline the seat and back. Lift up the handle to lock in position.



• Body Weight:


The strength of the synchro mechanism can be adjusted to the user's weight by turning the knob located under the seat. (Turn clockwise to increase resistance, and anti-clockwise to decrease resistance)



• Multi Adjustable Arm: (if fitted)


Height Adjustment:

Press the button on the outside of the armrest and slide up or down into the desired position. Release the button to lock.




Armpad Rotation:

The armpads rotate through 3 different positions, including 180° backwards, just in case they clash with your desk.



Armpad Lock:

The armpad will automatically lock in the front position. Slide control on the underside of armpad forward to release the lock and rotate to desired position.



orangebox